




Product Installation Instructions


LED SMART LIGHT | STELLAR ENERGY MANAGEMENT

SPRUNG


6. Attach **STANDARD Light Bracket Assembly** to **Stellar Light** and install onto Sprung beam using the same method mentioned in Step 3 (hole distance will vary depending on light). Plug **Light Power Cord (15")** into Quick Connect and *TWIST* connector cap to secure position.



7. Attach **INDIRECT Light Bracket Assembly** to **Stellar Light** and install onto Sprung beam using the same method mentioned in Step 6. Plug **Light Power Cord (30")** into Quick Connect and *TWIST* connector cap to secure position. Zip tie **Light Power Cord** to **Extension Bracket**.



Place **1 Hole Cover & Foam Assembly** over single Quick Connect.



- Repeat Step 6 to install additional **STANDARD Stellar Lights** next to each **Light Box** (4x4" J-Box 1 ½" deep). Plug **Light Power Cord** (15") into Quick Connect and *TWIST* connector cap to secure position.



- Repeat Step 7 to install additional **STANDARD Stellar Lights** next to each **Light Box** (4x4" J-Box 1 ½" deep). Plug **Light Power Cord** (30") into Quick Connect and *TWIST* connector cap to secure position.

